

5304530068 GENERIC OVEN THERMOMETER (SKU# L304432836)

5304530068 THERMOMÈTRE GÉNÉRIQUE POUR FOUR (UGS L304432836)

5304530068 TERMÓMETRO GENÉRICO PARA HORNO (SKU N.º L304432836)

Installation

1. Put the oven thermometer inside the oven on the rack as close to the center as possible.
2. Preheat your oven to 400 degrees, and then check the temperature on the thermometer.
3. Oven temperature will quickly fall every time the door is opened. Refrain from checking the temperature until the oven has preheated.

Installation

1. Placez le thermomètre du four à l'intérieur sur la grille aussi centrée que possible.
2. Préchauffez votre four à 400 degrés, puis vérifiez la température sur le thermomètre.
3. La température du four chutera rapidement chaque fois que la porte est ouverte. Évitez de vérifier la température avant que le four n'atteigne la température de préchauffage.

Instalación

1. Coloque el termómetro dentro del horno en la rejilla, lo más cerca posible del centro.
2. Precaliente el horno a 400 grados y luego verifique la temperatura en el termómetro.
3. La temperatura del horno disminuirá rápidamente cada vez que se abra la puerta. Absténgase de verificar la temperatura hasta que el horno se haya precalentado.