

## Microwaves

FFCM0934L S/W/B



### Signature Features

#### Easy-Set™ Start

Quickly start cooking—one to six minutes—with just one touch.

#### Ready-Select® Controls

Easily select options with the touch of a button.

#### Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

#### Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

### Countertop

#### Product Dimensions

|        |         |
|--------|---------|
| Height | 11-1/4" |
| Width  | 19-1/8" |
| Depth  | 13-7/8" |

#### More Easy-To-Use Features

##### Effortless™ Reheat

Reheat almost anything at the touch of a button.

##### Multiple-Stage Cooking Option

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

##### 10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

##### Control Lock Option

##### Electronic Clock/Timer

Helps you keep track of cook times.

##### Attractive Stainless Steel Exterior

##### Interior Light

Illuminates the contents of the microwave for increased visibility.

##### Large Glass Turntable

Even large items fit on our large glass turntable.

#### Available in:




Stainless (S)

White (W)

Black (B)

|                                  |   |
|----------------------------------|---|
| <b>Features</b>                  |   |
| Control/ Timing System           | Ready-Select*                                   |
| Exterior Door Finish             | Stainless Steel (S)/<br>Color-Coordinated (W/B) |
| Handle Design                    | Push Button                                     |
| <b>Microwave Features</b>        |   |
| Microwave Capacity (Cu.Ft.)      | 0.9   |
| Watts (IEC-705 Test Procedure)   | 900   |
| Interior Light                   | Yes   |
| Interior Color                   | White   |
| Turntable Diameter               | 10-5/8"   |
| Turntable On/Off                 |   |
| Control Lock                     | Yes   |
| Clock                            | Yes   |
| Touch Pad Buttons                | 23  |
| Power Levels                     | 10  |
| Accessory Metal Rack             |   |
| <b>Microwave Control Options</b> |   |
| Easy-Set™ Start                  | Yes   |
| Popcorn Button                   | Yes   |
| Chicken Nugget Button            |   |
| Baked Potato Button              | Yes   |
| Sensor Reheat Button             |   |
| Snack Button                     |   |
| Beverage                         | Yes   |
| Melt & Soften Options            |   |
| Auto Reheat Options              | 4   |
| Snack Menu Options               |   |
| Auto Cook Options                | 7   |
| Auto Defrost Options             | Yes   |
| Keep Warm                        |   |
| Add-30-Seconds                   | Yes   |
| Sensor Cooking Options           |   |
| Vegetable Cook Sensor            |   |
| Delay Start                      |   |
| User Preferences                 |   |
| <b>Power Ratings</b>             |   |
| Frequency (Mhz)                  | 2,450   |
| Watts @ 120 Volts                | 1,000   |
| Amps @ 120 Volts                 | 13.5  |
| <b>Specifications</b>            |   |
| Oven Interior Height             | 8-3/4"  |
| Oven Interior Width              | 12-3/8"   |
| Oven Interior Depth              | 13-1/2"   |
| Power Supply Connection Location | Rear  |
| Voltage Rating                   | 120V/60Hz/15A                                   |
| Minimum Circuit Required (Amps)  | 15  |
| Shipping Weight (Approx.)        | 31 Lbs.   |



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [frigidaire.com](http://frigidaire.com).



| Product Dimensions <sup>1</sup> |         |
|---------------------------------|---------|
| A - Height                      | 11-1/4" |
| B - Width                       | 19-1/8" |
| C - Depth                       | 13-7/8" |

<sup>1</sup>A minimum clearance of 3 inches is required above microwave oven and between microwave oven and adjacent walls.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)